

STYLE STARTS WITH WHAT'S INSIDE.

NEURO® SMOOTH XL IS CRAFTED FROM INDUSTRIAL-GRADE COMPONENTS UNDER RIGOROUS QUALITY CONTROL. **CREATIVE VISION, POWERED BY CUTTING-EDGE TECHNOLOGY. THAT'S INTELLIGENT STYLING.**

ANATOMY OF INTELLIGENT STYLING

- Heats up to 450° F in 45 seconds
- 1.5" premium IsoTherm titanium plates
- Dual voltage for worldwide use
- SmartSense microchip for lightning-fast heat recovery
- Customizable auto shut-off
- 9-foot swivel cord with hanging loop
- Cushioned plates with beveled edges
- 2-year warranty

INTELLIGENT STYLING TIPS

- 1 Begin with freshly washed hair, and towel dry to remove excess moisture.
- 2 Dry hair with your preferred Neuro® Dryer.
- 3 Apply Neuro™ Protect – HeatCTRL® Iron Hairspray to dry hair for thermal protection.
- 4 To ensure the smoothest finish and greatest control, smooth only a small amount of hair on each pass and move the tool slowly and steadily.
- 5 Run a fine-tooth comb through the hair ahead of the iron to distribute the hair evenly on the iron's surface.
- 6 To smooth: Begin approximately 1-2 inches from the scalp on the first pass, then move closer to the scalp on the second pass.
- 7 To flip or wave: Close the iron over the hair at the place where you wish the wave to begin, and rotate the tool 180 degrees. With firm tension, slowly pull the iron through the hair clockwise all the way through the ends.
- 8 To set your look, spray hair with Neuro™ Finish – HeatCTRL® Style Spray.



OPERATING INSTRUCTIONS



Mode Button



+/- Button



On / Off Button

TO SET TEMPERATURE

Use **+** and **-** buttons to select:

- 160-300° F for fine hair
- 310-390° F for medium hair
- 400-440° F for coarse hair
- 450° F for professional use

PRESS MODE BUTTON 1X
TO SET AUTO SHUT-OFF TIME
(0-120 minutes)

PRESS MODE BUTTON 2X
TO SELECT FAHRENHEIT (F)
OR CELSIUS (C)

PRESS MODE BUTTON 3X
TO RETURN TO MAIN SCREEN

UPGRADE TO
2YR
Warranty

REGISTER YOUR TOOL AT
WWW.NEUROHAIR.COM/REGISTER

Please call 1-888-522-8622 or email us at support@neurohair.com before returning any Neuro® Tools appliance.

Guaranteed **ONLY** when purchased within the professional beauty salon industry, **NOT** from a drugstore, supermarket, or other unauthorized source.

PROLONGER LA GARANTIE À 2 ANS.

ENREGISTREZ VOTRE OUTIL SUR
WWW.NEUROHAIR.COM/REGISTER

Veuillez appeler le 1-888-522-8622 ou nous envoyer un e-mail à support@neurohair.com avant de retourner tout appareil Neuro® Tools.

La garantie couvre **UNIQUEMENT** les produits achetés auprès d'un salon de coiffure professionnel et **NON PAS** les produits achetés dans une pharmacie, un supermarché ou toute autre source non autorisée.

MEJORA A GARANTÍA DE 2 AÑOS.

REGISTRE SU PRODUCTO EN
WWW.NEUROHAIR.COM/REGISTER

Llame al 1-888-522-8622 o envíenos un mensaje de correo electrónico a support@neurohair.com antes de devolver cualquier aparato Neuro® Tools.

Garantizado **SÓLO** cuando se adquiere dentro del sector de salones de belleza profesionales y **NO** en un supermercado u otro punto de venta no autorizado.

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING.

DANGER – Any appliance is electrically live, even when the switch is off. When not in use, always unplug the iron to prevent the risk of fire.

WARNING – To reduce the risk of burns, electrocution, fire or injury to persons and/or personal property:

- Use the iron only for the purpose described in this guide to prevent accidents, damage or malfunction.
- This appliance should never be left unattended when plugged in.
- Avoid multiple cables to a plug or use of an extension cord to prevent starting a fire from overheating.
- **KEEP AWAY FROM WATER** to prevent fire, electric shock, damage or malfunction.
- **KEEP AWAY FROM CHILDREN.**
- Do not handle the iron or cord with wet hands, as this may cause electric shock.
- Do not leave the iron in a position where it can fall or be pulled into a tub or sink. Keep the cord away from heated surfaces.
- **DO NOT WRAP THE CORD AROUND THE IRON.**
- Never place or insert objects on iron plates, due to the risk of causing fire, accidents or malfunction.
- Do not operate where oxygen is being administered to avoid the risk of fire.
- **DO NOT USE WHEN CORD HAS BEEN DAMAGED OR IF PLUG IS LOOSE.**
- **DO NOT REPAIR, TAMPER WITH, OR TRY TO RECONSTRUCT** the iron, otherwise electric shock, malfunction or accidents may result.
- When inserting or pulling out the plug, hold the plug firmly to prevent the cord from peeling and to prevent accidents or malfunction.
- Stop using immediately if you smell an offensive odor. If ignored, it could cause a fire or other accidents.
- Do not keep the iron in a damp place, such as a bathroom, or it may malfunction.
- Stop using the iron and remove from the power source when there is an earthquake or thunder.
- Unplug the iron from the power source when cleaning or wiping to prevent fire or electric shock.

MAINTENANCE

Daily Maintenance: For the safe use of the iron, check the following daily:

- Check the cord and surface of the cord. Never use if any parts are cracked, split, torn or damaged.
- Check the plug and never use if it is cracked, split or damaged.
- Check the plug pins and never use if transformed or damaged.
- Check the controller and do not use if cracked, split, broken or damaged.
- When not in use, clean and dry the entire iron and store in a cool, dry place.
- When ready to use, follow the directions for daily maintenance.

Daily Cleaning: To keep plates clean, unplug the iron from the power source, and once the iron is cool, wipe down plates after each use with a hot, damp towel.

WARNING: Do not wipe the iron with thinner, benzene, gasoline, lamp oil, and other solvents or chemicals, as that may cause accidents or malfunction, and may damage the iron and void the warranty.

Defects and Malfunction:

- Read all contents of the warranty completely and carefully before contacting the salon, the distributor or our Paul Mitchell® Pro Tools™ Warranty Center.
- John Paul Mitchell Systems® is not responsible for damage caused by misuse or due to operator accidents, such as dropping the appliance on the floor.

OPERATING INSTRUCTIONS

The iron has reached your selected temperature when the display screen reaches the desired temperature. You will hear a “beep” when the iron is ready to use. Once you have finished styling, turn off and unplug the iron. This iron has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit securely, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

WARRANTY GUIDE

IMPORTANT: Warranty valid only when appliance is purchased from an authorized John Paul Mitchell Systems® salon or distributor. Terms and conditions may vary depending on salon/authorized retailer's individual exchange or return policy.

WITH PROOF OF PURCHASE AND WITHIN 12 MONTHS OR 24 MONTHS IF TOOL IS REGISTERED

Exchange of defective appliance is at John Paul Mitchell Systems' discretion. If your Neuro® appliance fails to operate properly within the first 12 months of purchase, or within 24 months of purchase when registered, consumers can return the appliance to the salon where it was purchased (terms and conditions may vary depending on salon/authorized retailer's individual exchange or return policy) and stylists can return it to their distributor, making sure to bring the original proof of purchase. Otherwise, you may send us your appliance, postage paid, along with completed Warranty Request, your proof of purchase, and a money order or credit card information for \$14.00 (USD) payable to Paul Mitchell® Pro Tools™ Warranty Center to cover shipping, handling and insurance back to you. Repair or servicing of defective appliances is not offered. Warranty replacement of Limited Edition appliances is subject to availability; appliances may be replaced with a similar or equal product.

ANY IMPLIED WARRANTIES, OBLIGATIONS OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE 12-MONTH DURATION OF THIS WRITTEN LIMITED WARRANTY.

IN NO EVENT SHALL JOHN PAUL MITCHELL SYSTEMS® BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, WHATSOEVER.

This warranty gives you specific legal rights, and you may also have other rights, which may vary from state to state both in the USA and Canada.

If tool is registered, 12 months is automatically extended to 24 months.


THIS WARRANTY DOES NOT COVER

Normal wear and tear, which includes, but is not limited to, housing or plates scratches, and shorts or cuts in the power supply cord or plug. Damage due to misuse and abuse such as: Dropping, wrong voltage supply, neglecting safety precautions. Tampering, such as repair or attempted repair by unauthorized party. Neglect or lack of proper maintenance. Damage to cord: Do not wrap the cord around the iron as it can result in the cord breaking.

PLEASE BE ADVISED THAT IMPROPER USE OR MAINTENANCE OF YOUR APPLIANCE CAN RESULT IN DAMAGE TO PROPERTY OR PERSONAL INJURY, INCLUDING GREAT BODILY HARM. IT IS IMPORTANT TO FOLLOW THE INSTRUCTIONS. FAILURE TO DO SO CAN VOID THIS WARRANTY.

GENERAL SPECIFICATIONS

Model: NS15NAS
Rated Voltage: 110-240VAC
Frequency (Hz): 50/60Hz
Rated Wattage: 60W
Length of A.C. Cord: 9 ft./2.7 m
Weight (less cord): 300 g/10.6 oz./.66 lbs



NEURO® SMOOTH XL
INTELLIGENT STYLING
GUIDE D'UTILISATION • GUÍA DEL USUARIO

Distributed by
JOHN PAUL MITCHELL SYSTEMS
(USA) P.O. Box 10597, Beverly Hills, CA 90213-3597
Made in China.
neurohair.com